

Retro Guard

Surface Mounted Intumescent Fire and Smoke Seal

Brush Pile Version

Tested to BS476 : Part 22 to 1/2 Hour

Single Door Pack Consists

Contain 1off 5m Coil

Fitting Instructions

1. Ensure that the surfaces that are to be adhered to are free from dust or grease
2. Remove tape backing from the start of the coil and start from the bottom of the door frame positioning the pile against the stop
3. Continue up the frame side removing backing as you go, cut in both top corners of frame to ensure tight fit around frame perimeter
4. Use a sharp knife to cut to length and to cut out around the latch plate to allow door to engage
5. Close door and allow tape adhesive to cure off over night for best results

